









## Safe Work Practice / Job Procedure

### Work near overhead utilities

#### Potential Hazards

- Accidental contact
- Serious injury caused by the electrical current
- All personnel must ensure they have been appropriately trained by their supervisor.

#### Required Personal Protective Equipment and Devices

Foot Protection	Hearing Protection	High Visibility	Head Protection	Eye Protection	Face Protection	Hand Protection	Protective Clothing
							

#### Safe Work Practice

- Always be aware of overhead utilities
- Do Not surpass the safe distance zone
- Have an emergency preparedness plan
- Conduct a hazard assessment prior to commencement of work
- Do Not come into contact with overhead utilities

#### PPE Required

- Foot Protection
- High Visibility Vest
- Head Protection
- Eye Protection
- Hand Protection
- Protective Clothing

#### Safe Job Procedures

1. Complete the hazard assessment
2. Check the clearance prior to beginning task
3. Keep clear communication with the spotter
4. Complete the task
5. Once you have completed the task ensure that equipment or other hazards are removed from the work area safely

Created by: Dean Neuburger

Date: 2022-13-06

***If an emergency situation occurs while conducting this task, or there is an equipment malfunction, shut the equipment off immediately and follow the lock out procedure.***

**REPORT ANY HAZARDOUS SITUATION TO YOUR SUPERVISOR IMMEDIATELY**

**This SWP must be reviewed any time the task, equipment, or materials change and at minimum, every three years.**